



(512) 339-2456

Cosmopolitan



189774
Gobelet bas
low tumbler
vaso bajo
42 cl - 14 oz
Ø 8,5 cm - 3,3 inch
10,6 cm - 4,2 inch



184586
Gobelet bas
low tumbler
vaso bajo
32 cl - 10^{2/3} oz
Ø 8 cm - 3,1 inch
9,4 cm - 3,7 inch



184588
Gobelet haut
high tumbler
vaso alto
29 cl - 9^{2/3} oz
Ø 7 cm - 2,8 inch
10,7 cm - 4,21 inch



184589
Gobelet haut
high tumbler
vaso alto
35 cl - 11^{2/3} oz
Ø 6,5 cm - 2,5 inch
14,4 cm - 5,6 inch



189775
Gobelet haut
high tumbler
vaso alto
45 cl - 15 oz
Ø 6,6 cm - 2,6 inch
17,8 cm - 7 inch

Loop



184601
Gobelet haut
high tumbler
vaso alto
39 cl - 13 oz
Ø 6,6 cm - 2,6 inch
14,5 cm - 5,7 inch



184600
Gobelet bas
low tumbler
vaso bajo
35 cl - 11^{2/3} oz
Ø 7,94 cm - 3,12 inch
9,1 cm - 3,6 inch



184598
Gobelet bas/verrine
low tumbler
vaso bajo
19 cl - 5^{1/3} oz
Ø 6,7 cm - 2,6 inch
8,1 cm - 3,1 inch

