

CUPOLA

Form | Shape | Forma
 18610 | Cupola



Teekannen-Unterteil | *Base teapot* | Teiera senza coperchio
 0,40 ltr. | 14 oz. **34211**
 Deckel | *Lid* | Coperchio **34212**



Kaffeekannen-Unterteil | *Base coffee pot* | Caffettiera senza coperchio
 0,30 ltr. | 10 1/2 oz. **34001**
 Deckel | *Lid* | Coperchio **34002**

132

Rosenthal | Hotel & Restaurant Service | Cupola | 18610



Gießer | *Creamer* | Lattiera
 0,03 ltr. | 1 oz. **34403**
 0,15 ltr. | 5 1/4 oz. **34415**
 0,30 ltr. | 10 1/2 oz. **34430**



Zuckerdosens-Unterteil | *Base sugar bowl* | Zuccheriera senza coperchio
 0,15 ltr. | 5 1/4 oz. **34316**
 Deckel | *Lid* | Coperchio **34317**

Dekor | *Decor* | Decoro
800001 | weiß | *white* | bianco



Obertasse | *Cup* | Tazza
0,10 ltr. | 3 1/2 oz. **34712**
Untertasse | *Saucer* | Piattino
12 cm | 4 3/4 in. **34611**



Obertasse | *Cup* | Tazza
0,22 ltr. | 7 3/4 oz. **34642**
Untertasse | *Saucer* | Piattino
15 cm | 6 in. **34636**



Obertasse | *Cup* | Tazza
0,16 ltr. | 5 5/8 oz. **34622**
Untertasse | *Saucer* | Piattino
15 cm | 6 in. **34636**



Kaffeebecher | *Coffee mug* | Mug
0,25 ltr. | 8 3/4 oz. **34650**
Untertasse | *Saucer* | Piattino
15 cm | 6 in. **34636**



Obertasse | *Cup* | Tazza
0,18 ltr. | 6 1/3 oz. **34627**
Untertasse | *Saucer* | Piattino
15 cm | 6 in. **34636**



Combi Untertasse | *Saucer Combi* | Piattino combi
16 cm | 6 1/4 in. **34645**
Eierbecher mit Ablage | *Flanged egg cup* | Portauovo
35525 (Form | *Shape* | Forma 10630)

CUPOLA

Form | Shape | Forma
18610 | Cupola



Teller flach | *Plate flat* | Piatto piano
16 cm | 6 1/4 in. **30016**
20 cm | 7 7/8 in. **30020**
23 cm | 9 in. **30023**
26 cm | 10 1/4 in. **30026**
28 cm | 11 in. **30028**
31 cm | 12 1/4 in. **30031**



Teller tief | *Plate deep* | Piatto fondo
23 cm | 9 in. **30123**



Suppentasse | *Soup cup* | Tazza brodo
0,25 ltr. | 8 3/4 oz. **30476**
Suppenbowl | *Soup bowl* | Coppa brodo
0,25 ltr. | 8 3/4 oz. **30725**
Combi Untertasse | *Saucer Combi* | Piattino combi
16 cm | 6 1/3 in. **34645**



Sauciere | *Sauceboat* | Salsiera
0,30 ltr. | 10 1/2 oz. **31610**
Combi Untertasse | *Saucer Combi* | Piattino combi
16 cm | 6 1/3 in. **34645**

Dekor | *Decor* | Decoro
 80001 | weiß | *white* | bianco



Platte oval | *Platter oval* | Piatto ovale
 28 cm | 11 1/4 in. **32628**
 33 cm | 13 in. **32633**



Butternäpfchen / Eierbecher | *Butter bowl / egg cup* |
 Coppetta burro / portauovo
35405

Bowl | *Bowl small* | Coppetta piccola
 8 cm | 3 1/8 in. **30608**



Kompott | *Fruit* | Coppetta
 12 cm | 4 3/4 in. **30512**

Schüssel | *Salad bowl* | Insalatiera
 12 cm | 4 3/4 in. **33012**
 15 cm | 6 in. **33015**
 17 cm | 6 2/3 in. **33017**



Vase | *Vase* | Vaso
 10 cm | 4 in. **36010**

Ascher | *Ashtray* | Posacenere
 10 cm | 4 in. **37010**



Salzstreuer | *Salt* | Spargisale
35030

Pfefferstreuer | *Pepper* | Spargipepe
35035