



FREE SPIRIT

(512) 339-2456

Form | Shape | Forma
11750 | Free Spirit

74 Rosenthal | Hotel & Restaurant Service | Free Spirit | 11750



Schale 32 cm auf Fuß | Bowl 32 cm on stand |
Coppa con piede 32 cm
Schale 32, 1,50 ltr. | 52 3/4 oz. **35394**



Schale »Spirit« 19 auf Fuß | Bowl »Spirit« 19 on stand |
Alzatina a due ali 19 »Spirit«
Schale 19, 0,75 ltr. | 26 1/2 oz. **35393**




Schale | Bowl | Coppa
Schale 32, 1,50 ltr. | 52 3/4 oz. **35432**



Schale »Spirit« | Bowl »Spirit« | Coppa »Spirit«
Schale 12, 0,18 ltr. | 6 1/3 oz. **35412**
Schale 19, 0,75 ltr. | 26 1/2 oz. **35419**



3-er Schale | Triple bowl | Coppa tre scomparti
32 x 10 cm | 12 2/3 in. **35396**



2-er Schale | Double bowl | Coppa due scomparti
36 x 16 cm | 14 1/8 in. **35395**



4-er Schale | Quadruple bowl | Coppa quattro scomparti
24 x 24 cm | 9 1/2 in. **35397**

Dekor | *Decor* | Decoro
800001 | weiß | *white* | bianco



Teller tief quadratisch | *Gourmet plate deep square* |
Piatto fondo quadrato
23 cm | 9 in. **31411**
29 cm | 11 1/2 in. **31529**




Teller flach quadratisch | *Plate flat square* | Piatto piano quadrato
14 cm | 5 1/2 in. **31403**
21 cm | 8 1/4 in. **31401**
27 cm | 10 5/8 in. **31402**

Platzteller | *Service plate* | Piatto segnaposto
34 cm | 13 1/2 in. **31155**



Gourmetteller flach oval | *Gourmet plate flat oval* |
Piatto piano ovale a goccia
40 cm | 15 3/4 in. **31451**



Platte flach rechteckig | *Platter flat rectangular* |
Piatto piano rettangolare
27 x 18 cm | 10 1/2 in. **32677**
32 x 21 cm | 12 2/3 in. **32682**



Schale | *Bowl* | Coppa
9 x 10 cm | 0,05 ltr. **35388**
11 x 13 cm | 0,13 ltr. **35389**
15 x 17 cm | 0,25 ltr. **35390**
19 x 22 cm | 0,50 ltr. **35391**
25 x 18 cm | 2,00 ltr. **35392**



Beilage Halbmond | *Accent dish moon-shaped* | Mezza luna
18 x 9 cm | 7 in. **35329**
21 x 11 cm | 8 1/4 in. **35330**
27 x 14 cm | 10 1/2 in. **35331**

FREE SPIRIT



Form | *Shape* | Forma
11750 | Free Spirit

Dekor | *Decor* | Decoro
800001 | weiß | *white* | bianco

(512) 339-2456

76

Rosenthal | Hotel & Restaurant Service | Free Spirit | 11750



Obertasse | *Cup* | Tazza
0,09 ltr. | 3 1/8 oz.

34745

Untertasse quadratisch | *Saucer square* | Piattino quadrato
10 cm | 4 in.

34744



Obertasse | *Cup* | Tazza
0,25 ltr. | 8 3/4 oz.

34746

Untertasse quadratisch | *Saucer square* | Piattino quadrato
15 cm | 6 in.

34636



Obertasse | *Cup* | Tazza
0,28 ltr. | 9 7/8 oz.

34737

Untertasse quadratisch | *Saucer square* | Piattino quadrato
15 cm | 6 in.

34636



Karaffe | *Carafe* | Caraffa
25 cm | 0,90 ltr.

34481



Dosen-Unterteil / Schale | *Base sugar bowl / bowl* | Zuccheriera
senza coperchio / coppa
11 x 13 cm | 0,13 ltr.

35389

Deckel mit Einschnitt | *Lid with indent* | Coperchio con tacca
11 cm | 4 1/3 in.

34312

Gießer | *Creamer* | Lattiera
10 cm | 0,16 ltr.

34416



Eierbecher | *Egg cup* | Portauovo
15 x 9 cm | 6 in.

35520





FREE SPIRIT GLAS

(512) 339-2456

Form | Shape | Forma
69809 | Free Spirit Glas |

Dekor | Decor | Decoro
016001 | Klarglas | *crystall-clear* | trasparente



Platzteller flach quadratisch | *Service plate flat square* |
Piatto segnaposto quadrato
32 cm | 12 5/8 in. **45041**



Schale | *Bowl* | Coppetta
10 cm | 0,04 ltr. **45210**



Schale | *Bowl* | Coppa
20 cm | 0,70 ltr. **45320**



Beilage Halbmond | *Accent dish moon-shaped* | Mezza luna
18 x 9 cm | 7 in. **45865**



Schale | *Bowl* | Coppetta
9 x 10 cm | 0,05 ltr. **45209**

