



# IN.GREDIENTI

Form | *Shape* | Forma  
11780 | in.ingredienti

Dekore | *Decors* | Decori  
800001 | weiß | *white* | bianco  
414818 | Seta<sup>2</sup> semi-biscuit |  

82

Rosenthal | Hotel & Restaurant Service | in.ingredienti | 11780



»Giro«

Teller tief | *Plate deep* | Piatto fondo  
22 cm | 8 2/3 in. **30122**



»Riso«

Teller flach | *Plate flat* | Piatto piano  
30 cm | 12 in. **30030**



»Pasta«

Teller tief | *Plate deep* | Piatto fondo  
26 cm | 10 1/4 in. **30126**



»Impronte«

Teller tief | *Plate deep* | Piatto fondo  
22 cm | 8 2/3 in. **31302**



»Pian«

Teller flach | *Plate flat* | Piatto piano  
29 cm | 11 3/8 in. **30029**



»Piano ovale«

Teller flach oval | *Plate flat oval* | Piatto piano ovale  
31 x 23 cm | 12 1/4 in. **30151**



»Bugia«

Teller tief | *Plate deep* | Piatto fondo  
14 x 11 cm | 5 1/2 in. **31304**



»Coppetta«

Schale | *Bowl* | Coppetta  
7 cm | 2 2/3 in. **35407**



»Piastra«

Platte flach rechteckig | *Platter flat rectangular* | Piatto rettangolare  
 24 x 12 cm | 9 1/2 in. **32624**  
 33 x 16 cm | 13 in. **32633**



»TOC«

Platte flach | *Platter flat* | Piatto piano  
 28 cm | 11 in. **32628**  
 39 cm | 15 1/3 in. **32639**



»Impronta«

Teller tief | *Plate deep* | Piatto fondo  
 22 cm | 8 2/3 in. **31303**



»Fondo«

Teller tief | *Plate deep* | Piatto fondo  
 27 x 19 cm | 10 5/8 in. **30171**



»Fondo ovale«

Teller tief oval | *Plate deep oval* | Piatto fondo ovale  
 32 x 20 cm | 12 2/3 in. **30172**




»Goccia«

Teller tief rund | *Plate deep* | Piatto fondo  
 15 cm | 6 in. **30115**



»Tegamino«

Schale | *Bowl* | Coppa  
 24 x 15 cm | 9 1/2 in. **35482**



»Ovo«

Schale oval | *Bowl oval* | Coppa ovale  
 20 x 13 cm | 8 in. **35483**

