

JADE



(512) 339-2456

Form | Shape | Forma
10640 | Fine Bone China | Jade

98

Rosenthal | Hotel & Restaurant Service | Jade | 10640



Teekannen-Unterteil | *Base teapot* | Teiera senza coperchio
0,40 ltr. | 14 oz. **34211**
Deckel | *Lid* | Coperchio **34212**



Kaffeekannen-Unterteil | *Base coffee pot* | Caffettiera senza coperchio
0,30 ltr. | 10 1/2 oz. **34001**
Deckel | *Lid* | Coperchio **34002**



Teekannen-Unterteil | *Base teapot* | Teiera senza coperchio
0,45 ltr. | 15 7/8 oz. **34261**
0,85 ltr. | 30 oz. **34264**
Deckel klein | *Lid small* | Coperchio piccolo **34262**
Deckel groß | *Lid large* | Coperchio grande **34265**



Krug | *Jug* | Brocca **34492**
0,75 ltr. | 26 7/8 oz.



Senf-/Zuckerdosens-Unterteil | *Condiment bowl base* |
Coppetta salsa senza coperchio
0,09 ltr. | 3 1/8 oz. **34366**
Deckel mit Einschnitt | *Lid with indent* | Coperchio con tacca **34367**



Gießer | *Creamer* | Lattiera
0,05 ltr. | 1 3/4 oz. **34405**
0,20 ltr. | 7 oz. **34420**

Zuckerdosens-Unterteil | *Base sugar bowl* |
Zuccheriera senza coperchio
0,25 ltr. | 8 3/4 oz. **34341**
Deckel | *Lid* | Coperchio **34342**

Zuckerbriefchenbehälter | *Bowl for sachets of sugar* | Portabustine
10 x 7 cm | 4 in. **35550**



Zucker/Gießer Tablett | *Sugar/cream stand* | Vassoio multiuso
25 cm | 10 in. **32963**

Dekor | *Decor* | Decoro
800001 | weiß | *white* | bianco



Obertasse | *Cup* | Tazza
0,10 ltr. | 3 1/2 oz. **34812**
Untertasse | *Saucer* | Piattino
12 cm | 4 3/4 in. **34611**



Obertasse stapelbar | *Cup stackable* | Tazza impilabile
0,10 ltr. | 3 1/2 oz. **34673**
0,20 ltr. | 7 oz. **34674**
Untertasse | *Saucer* | Piattino
12 cm | 4 3/4 in. **34611**
15 cm | 6 in. **34636**



Obertasse | *Cup* | Tazza
0,20 ltr. | 7 oz. **34749**
Untertasse | *Saucer* | Piattino
15 cm | 6 in. **34636**



Obertasse | *Cup* | Tazza
0,22 ltr. | 7 3/4 oz. **34642**
Untertasse | *Saucer* | Piattino
16 cm | 6 1/4 in. **34741**



Becher mit Henkel | *Mug with handle* | Mug con manico
0,40 ltr. | 14 oz. **34659**



Obertasse | *Cup* | Tazza
0,38 ltr. | 13 3/8 oz. **34751**
Untertasse | *Saucer* | Piattino
18 cm | 7 in. **34750**



JADE

(512) 339-2456

Form | Shape | Forma
10640 | Fine Bone China | Jade

100

Rosenthal | Hotel & Restaurant Service | Jade | 10640



Fahnteller flach | *Rim plate flach* | Piatto piano con falda

16 cm 6 1/4 in.	31116
19 cm 7 1/2 in.	31119
23 cm 9 in.	31123
25 cm 10 in.	31125
27 cm 10 1/2 in.	31127



Fahnteller tief | *Rim plate deep* | Piatto fondo con falda

23 cm 9 in.	31223
29 cm 11 3/8 in.	31229

Platzteller flach | *Service rim plate flach* | Piatto segnaposto

31 cm 12 1/4 in.	31161
--------------------	-------



Suppentassen-Unterteil | *Soup cup* | Tazza consommé

0,25 ltr. 8 3/4 oz.	30476
-----------------------	-------

Deckel | *Lid* | Coperchio 30478

Untertasse | *Saucer* | Piattino

16 cm 6 1/4 in.	34741
-------------------	-------



Coupeteller tief | *Coupe plate deep* | Piatto fondo coupe

19 cm 7 1/2 in.	30119
-------------------	-------



Suppentasse | *Soup cup* | Tazza brodo

0,35 ltr. 12 1/3 oz.	30479
------------------------	-------

Untertasse | *Saucer* | Piattino

18 cm 7 in.	34750
---------------	-------



Suppenbowl | *All purpose bowl* | Coppa multiuso

0,35 ltr. 12 1/3 oz.	30726
------------------------	-------

Untertasse | *Saucer* | Piattino

18 cm 7 in.	34750
---------------	-------

Dekor | *Decor* | Decoro
800001 | weiß | *white* | bianco




Coupeteller flach | *Coupe plate flach* | Piatto piano coupe

15 cm 6 in.	30015
20 cm 7 7/8 in.	30020
23 cm 9 in.	30023
25 cm 9 7/8 in.	30025
28 cm 11 in.	30028
31 cm 12 1/4 in.	30031
36 cm 14 1/8 in.	30036
41 cm 16 1/8 in.	30041
47 cm 18 1/2 in.	30047




Platte oval | *Platter oval* | Piatto ovale

24 cm 9 1/2 in.	35324
30 cm 11 3/4 in.	32630
35 cm 13 3/4 in.	32635
43 cm 17 in.	32643



Platte rechteckig | *Platter rectangular* | Piatto rettangolare
48 x 16 cm | 18 3/4 in. **32698**



Platte rechteckig | *Platter rectangular* | Piatto rettangolare
25 x 19 cm | 10 in. **32675**



Teller quadr. flach | *Square plate flat* | Piatto piano quadrato
23 cm | 9 in. **31404**
27 cm | 10 5/8 in. **31402**

JADE



(512) 339-2456

Form | Shape | Forma
10640 | Fine Bone China | Jade

102

Rosenthal | Hotel & Restaurant Service | Jade | 10640



Teeschale | *Tea cup* | Tazzina the orientale
0,10 ltr. | 3 1/2 oz. **34885**
Deckel | *Lid* | Coperchio **34886**
Untertasse | *Saucer* | Sottocoppa **34884**

0,15 ltr. | 5 1/4 oz. **34889**
Deckel | *Lid* | Coperchio **34890**
Untertasse | *Saucer* | Sottocoppa **34888**



Schüssel | *Bowl* | Coppa
10 cm | 4 in. **30610**
11 cm | 4 1/3 in. **30611**
14 cm | 5 1/2 in. **30614**
20 cm | 7 7/8 in. **33020**
23 cm | 9 in. **33023**
28 cm | 11 in. **33028**

Deckel | *Lid* | Coperchio
10 cm | 4 in. **30641**
11 cm | 4 1/3 in. **30642**
14 cm | 5 1/2 in. **30643**
20 cm | 7 7/8 in. **33063**
23 cm | 9 in. **33064**
28 cm | 11 in. **33065**



Sauciere | *Sauceboat* | Salsiera
0,45 ltr. | 15 7/8 oz. **31615**
Untertasse oval | *Saucer oval* | Piattino ovale
24 cm | 9 1/2 in. **31635**



Teeschale | *Tea cup* | Tazzina the
0,09 ltr. | 3 1/8 oz. **34891**
Sake Becher | *Sake cup* | Coppetta Sakè
0,03 ltr. | 1 oz. **35504**



Schälchen rund | *Round dish* | Piattino tondo
8 cm | 3 in. **35401**
10 cm | 4 in. **35410**



Kompott | *Bowl* | Coppa frutta
16 cm | 6 1/4 in. **30516**
Schüssel | *Bowl* | Coppa
21 cm | 8 1/4 in. **33021**
24 cm | 9 1/2 in. **33024**

Dekor | Decor | Decoro
800001 | weiß | white | bianco




Schälchen rund geteilt | *Round compartment dish* |
Piattino tondo a due scomparti
10 cm | 4 in. **35472**

Schälchen quadratisch geteilt | *Square compartment dish* |
Piattino quadrato a due scomparti
8 cm | 3 1/8 in. **35473**



Soja / Essig-Kännchen m. Dkl. | *Vinegar / soy sauce port with lid* |
Acetiera / portasoia con coperchio
0,10 ltr. | 3 1/2 oz. **35003**

Zahnstocherbecher | *Toothpick holder* | Portastuzzicadenti
6 cm | 2 1/4 in. **35524**



Löffel / Chopstick Ablage | *Spoon & chopstick stand* | Portacucchiaio /
portabacchette **35537**

Chopstickablage | *Chopstick stand* | Portabacchette
6 x 2 cm | 2 1/2 in. **35538**



Salzstreuer | *Salt shaker* | Spargisale
8 cm | 3 1/8 oz. **35030**

Pfefferstreuer | *Pepper shaker* | Spargipepe
8 cm | 3 1/8 oz. **35035**



Schälchen oval | *Oval dish / spoon stand* | Piattino ovale multiuso
10 cm | 4 in. **35474**

Schälchen rechteckig | *Towel dish* | Piattino rettangolare multiuso
12 x 9 cm | 4 3/4 in. **35475**



Löffel | *Spoon* | Cucchiaio
11 cm | 4 1/3 in. **35691**
13 cm | 5 1/8 in. **35692**
23 cm | 9 in. **35693**



Eierbecher | *Flanged egg cup* | Portauovo
13 cm | 5 1/8 in. **35525**



Vase | *Vase* | Vaso
14 cm | 5 1/2 in. **36014**

Ascher rechteckig | *Ashtray rectangular* | Posacenere rettangolare
11 x 9 cm | 4 1/3 in. **37111**