

# JADE

Form | Shape | Forma  
10640 | Fine Bone China | Jade

98

Rosenthal | Hotel & Restaurant Service | Jade | 10640



Teekannen-Unterteil | *Base teapot* | Teiera senza coperchio  
0,40 ltr. | 14 oz. **34211**  
Deckel | *Lid* | Coperchio **34212**



Kaffeekannen-Unterteil | *Base coffee pot* | Caffettiera senza coperchio  
0,30 ltr. | 10 1/2 oz. **34001**  
Deckel | *Lid* | Coperchio **34002**



Teekannen-Unterteil | *Base teapot* | Teiera senza coperchio  
0,45 ltr. | 15 7/8 oz. **34261**  
0,85 ltr. | 30 oz. **34264**  
Deckel klein | *Lid small* | Coperchio piccolo **34262**  
Deckel groß | *Lid large* | Coperchio grande **34265**



Krug | *Jug* | Brocca **34492**  
0,75 ltr. | 26 7/8 oz.



Senf-/Zuckerdosens-Unterteil | *Condiment bowl base* |  
Coppetta salsa senza coperchio  
0,09 ltr. | 3 1/8 oz. **34366**  
Deckel mit Einschnitt | *Lid with indent* | Coperchio con tacca **34367**



Gießer | *Creamer* | Lattiera  
0,05 ltr. | 1 3/4 oz. **34405**  
0,20 ltr. | 7 oz. **34420**

Zuckerdosens-Unterteil | *Base sugar bowl* |  
Zuccheriera senza coperchio  
0,25 ltr. | 8 3/4 oz. **34341**  
Deckel | *Lid* | Coperchio **34342**

Zuckerbriefchenbehälter | *Bowl for sachets of sugar* | Portabustine  
10 x 7 cm | 4 in. **35550**



Zucker/Gießer Tablett | *Sugar/cream stand* | Vassoio multiuso  
25 cm | 10 in. **32963**

**Dekor | Decor | Decoro**  
**80001 | weiß | white | bianco**



Obertasse | *Cup* | Tazza  
 0,10 ltr. | 3 1/2 oz. **34812**  
 Untertasse | *Saucer* | Piattino  
 12 cm | 4 3/4 in. **34611**



Obertasse stapelbar | *Cup stackable* | Tazza impilabile  
 0,10 ltr. | 3 1/2 oz. **34673**  
 0,20 ltr. | 7 oz. **34674**  
 Untertasse | *Saucer* | Piattino  
 12 cm | 4 3/4 in. **34611**  
 15 cm | 6 in. **34636**



Obertasse | *Cup* | Tazza  
 0,20 ltr. | 7 oz. **34749**  
 Untertasse | *Saucer* | Piattino  
 15 cm | 6 in. **34636**



Obertasse | *Cup* | Tazza  
 0,22 ltr. | 7 3/4 oz. **34642**  
 Untertasse | *Saucer* | Piattino  
 16 cm | 6 1/4 in. **34741**



Becher mit Henkel | *Mug with handle* | Mug con manico  
 0,40 ltr. | 14 oz. **34659**



Obertasse | *Cup* | Tazza  
 0,38 ltr. | 13 3/8 oz. **34751**  
 Untertasse | *Saucer* | Piattino  
 18 cm | 7 in. **34750**

# JADE

Form | Shape | Forma  
10640 | Fine Bone China | Jade

100

Rosenthal | Hotel & Restaurant Service | Jade | 10640



Fahnteller flach | *Rim plate flach* | Piatto piano con falda

16 cm | 6 1/4 in.      **31116**  
19 cm | 7 1/2 in.      **31119**  
23 cm | 9 in.          **31123**  
25 cm | 10 in.        **31125**  
27 cm | 10 1/2 in.    **31127**

Platzteller flach | *Service rim plate flach* | Piatto segnaposto

31 cm | 12 1/4 in.    **31161**



Fahnteller tief | *Rim plate deep* | Piatto fondo con falda

23 cm | 9 in.          **31223**  
29 cm | 11 3/8 in.    **31229**



Suppentassen-Unterteil | *Soup cup* | Tazza consommé  
0,25 ltr. | 8 3/4 oz.    **30476**

Deckel | *Lid* | Coperchio    **30478**

Untertasse | *Saucer* | Piattino  
16 cm | 6 1/4 in.        **34741**



Coupeteller tief | *Coupe plate deep* | Piatto fondo coupe  
19 cm | 7 1/2 in.        **30119**



Suppentasse | *Soup cup* | Tazza brodo  
0,35 ltr. | 12 1/3 oz.    **30479**

Untertasse | *Saucer* | Piattino  
18 cm | 7 in.            **34750**



Suppenbowl | *All purpose bowl* | Coppa multiuso  
0,35 ltr. | 12 1/3 oz.    **30726**

Untertasse | *Saucer* | Piattino  
18 cm | 7 in.            **34750**

Dekor | *Decor* | *Decoro*  
 800001 | weiß | *white* | *bianco*




Coupeteller flach | *Coupe plate flach* | *Piatto piano coupe*

15 cm   6 in.	<b>30015</b>
20 cm   7 7/8 in.	<b>30020</b>
23 cm   9 in.	<b>30023</b>
25 cm   9 7/8 in.	<b>30025</b>
28 cm   11 in.	<b>30028</b>
31 cm   12 1/4 in.	<b>30031</b>
36 cm   14 1/8 in.	<b>30036</b>
41 cm   16 1/8 in.	<b>30041</b>
47 cm   18 1/2 in.	<b>30047</b>



Platte oval | *Platter oval* | *Piatto ovale*

24 cm   9 1/2 in.	<b>35324</b>
30 cm   11 3/4 in.	<b>32630</b>
35 cm   13 3/4 in.	<b>32635</b>
43 cm   17 in.	<b>32643</b>



Platte rechteckig | *Platter rectangular* | *Piatto rettangolare*  
 48 x 16 cm | 18 3/4 in. **32698**



Platte rechteckig | *Platter rectangular* | *Piatto rettangolare*  
 25 x 19 cm | 10 in. **32675**



Teller quadr. flach | *Square plate flat* | *Piatto piano quadrato*  
 23 cm | 9 in. **31404**  
 27 cm | 10 5/8 in. **31402**

# JADE

Form | Shape | Forma  
10640 | Fine Bone China | Jade

102

Rosenthal | Hotel & Restaurant Service | Jade | 10640



Teeschale | *Tea cup* | Tazzina the orientale  
0,10 ltr. | 3 1/2 oz. **34885**  
Deckel | *Lid* | Coperchio **34886**  
Untertasse | *Saucer* | Sottocoppa **34884**

0,15 ltr. | 5 1/4 oz. **34889**  
Deckel | *Lid* | Coperchio **34890**  
Untertasse | *Saucer* | Sottocoppa **34888**



Schüssel | *Bowl* | Coppa  
10 cm | 4 in. **30610**  
11 cm | 4 1/3 in. **30611**  
14 cm | 5 1/2 in. **30614**  
20 cm | 7 7/8 in. **33020**  
23 cm | 9 in. **33023**  
28 cm | 11 in. **33028**

Deckel | *Lid* | Coperchio  
10 cm | 4 in. **30641**  
11 cm | 4 1/3 in. **30642**  
14 cm | 5 1/2 in. **30643**  
20 cm | 7 7/8 in. **33063**  
23 cm | 9 in. **33064**  
28 cm | 11 in. **33065**



Sauciere | *Sauceboat* | Salsiera  
0,45 ltr. | 15 7/8 oz. **31615**

Untertasse oval | *Saucer oval* | Piattino ovale  
24 cm | 9 1/2 in. **31635**



Teeschale | *Tea cup* | Tazzina the  
0,09 ltr. | 3 1/8 oz. **34891**

Sake Becher | *Sake cup* | Coppetta Sakè  
0,03 ltr. | 1 oz. **35504**



Schälchen rund | *Round dish* | Piattino tondo  
8 cm | 3 in. **35401**  
10 cm | 4 in. **35410**



Kompott | *Bowl* | Coppa frutta  
16 cm | 6 1/4 in. **30516**

Schüssel | *Bowl* | Coppa  
21 cm | 8 1/4 in. **33021**  
24 cm | 9 1/2 in. **33024**

**Dekor | Decor | Decoro**  
**800001 | weiß | white | bianco**




Schälchen rund geteilt | *Round compartment dish* |  
Piattino tondo a due scomparti  
10 cm | 4 in. **35472**

Schälchen quadratisch geteilt | *Square compartment dish* |  
Piattino quadrato a due scomparti  
8 cm | 3 1/8 in. **35473**



Soja / Essig-Kännchen m. Dkl. | *Vinegar / soy sauce port with lid* |  
Acetiera / portasoia con coperchio  
0,10 ltr. | 3 1/2 oz. **35003**

Zahnstocherbecher | *Toothpick holder* | Portastuzzicadenti  
6 cm | 2 1/4 in. **35524**



Löffel / Chopstick Ablage | *Spoon & chopstick stand* | Portacucchiaino /  
portabacchette **35537**

Chopstickablage | *Chopstick stand* | Portabacchette  
6 x 2 cm | 2 1/2 in. **35538**



Salzstreuer | *Salt shaker* | Spargisale  
8 cm | 3 1/8 oz. **35030**

Pfefferstreuer | *Pepper shaker* | Spargipepe  
8 cm | 3 1/8 oz. **35035**



Schälchen oval | *Oval dish / spoon stand* | Piattino ovale multiuso  
10 cm | 4 in. **35474**

Schälchen rechteckig | *Towel dish* | Piattino rettangolare multiuso  
12 x 9 cm | 4 3/4 in. **35475**



Löffel | *Spoon* | Cucchiaino  
11 cm | 4 1/3 in. **35691**  
13 cm | 5 1/8 in. **35692**  
23 cm | 9 in. **35693**



Eierbecher | *Flanged egg cup* | Portauovo  
13 cm | 5 1/8 in. **35525**



Vase | *Vase* | Vaso  
14 cm | 5 1/2 in. **36014**

Ascher rechteckig | *Ashtray rectangular* | Posacenere rettangolare  
11 x 9 cm | 4 1/3 in. **37111**