

# LOFT

Form | Shape | Forma  
11900 | Loft

Dekor | Decor | Decoro  
800001 | weiß | white | bianco



Espresso-Obertasse | Cup | Tazza  
0,08 ltr. | 2 7/8 oz. **14717**

Espresso-Untertasse | Saucer | Piattino  
11,5 cm | 4 1/2 in. **14716**



Espresso-Obertasse stapelbar | Cup stackable | Tazza impilabile  
0,11 ltr. | 3 7/8 oz. **16727**

Espresso-Untertasse | Saucer | Piattino  
12,5 cm | 5 in. **16726**



Tee-Obertasse | Cup | Tazza  
0,25 ltr. | 8 7/8 oz. **14642**

Tee-Untertasse | Saucer | Piattino  
17,5 cm | 6 7/8 in. **14641**



Kaffee-Obertasse stapelbar | Cup stackable | Tazza impilabile  
0,20 ltr. | 7 oz. **16747**

Kaffee-Untertasse | Saucer | Piattino  
16,5 cm | 6 1/2 in. **16746**



Kombi-Obertasse | Cup | Tazza  
0,34 ltr. | 12 oz. **14772**

Kombi-Untertasse | Saucer | Piattino  
18 cm | 7 in. **14771**



Tee-/Cappuccino-Obertasse stapelbar | Cup stackable | Tazza impilabile  
0,21 ltr. | 7 1/2 oz. **16647**

Becher mit Henkel stapelbar | Mug stackable | Mug impilabile  
0,33 ltr. | 11 1/2 oz. **15573**  
0,38 ltr. | 13 3/8 oz. **15574**

Untertasse | Saucer | Piattino  
16,5 cm | 6 1/2 in. **16646**  
18 cm | 7 in. **15481**



Müslischale | Cereal dish | Coppetta cereali  
0,50 ltr. | 17 2/3 oz. **15453**


Untertasse | Saucer | Piattino  
26 x 16 cm | 10 2/5 in. **15581**




Untertasse Müslischale/Becher | Saucer cereal bowl/mug |  
Piattino coppetta cereali/mug  
26 x 16 cm | 10 2/5 in. **15581**

# LOFT

Form | Shape | Forma  
11900 | Loft



Teller flach | *Plat flat* | Piatto piano  
18 cm | 7 in. **10218**  
22 cm | 8 2/3 in. **10222**  
28 cm | 11 in. **10229**  
33 cm | 13 in. **10263**



Gourmetteller / Schale | *Gourmet plate / bowl* | Piatto gourmet / coppa  
33 cm | 13 in. **10733**  
Teller tief | *Plat deep* | Piatto fondo  
24 cm | 9 1/2 in. **10324**



Platte flach oval | *Platter flat oval* | Piatto piano ovale  
34 cm | 13 1/2 in. **12734**  
40 cm | 16 in. **12740**



Platte tief oval | *Platter deep oval* | Piatto fondo ovale  
27 cm | 10 5/8 in. **12527**  
Bowl tief oval | *Bowl deep oval* | Coppa fonda ovale  
17 cm | 6 2/3 in. **10575**



Abdeckung zu Schüsseln | *Lid for bowls* | Coperchio coppa  
23 cm | 9 in. **13524**  
Bowl nieder rund | *Bowl low round* | Coppa bassa tonda  
23 cm | 9 in. **13123**  
Bowl hoch rund | *Bowl tall round* | Coppa alta tonda  
23 cm | 9 in. **13323**



Bowl tief rund | *Bowl deep round* | Coppa fonda rotonda  
13 cm | 5 1/8 in. **10571**  
15 cm | 6 in. **10570**

Dekor | *Decor* | Decoro  
800001 | weiß | *white* | bianco



Platte/Teller flach quadratisch | *Platter flat square* |

Piatto piano quadrato

13 cm | 5 1/8 in. **15258**

19 cm | 7 1/2 in. **12019**

27 cm | 10 5/8 in. **12027**

33 cm | 13 in. **16531**



Platte tief quadratisch | *Platter deep square* | Piatto fondo quadrato

22 cm | 8 2/3 in. **12072**



Bowl tief quadratisch | *Bowl deep square* | Coppa fonda quadrata

12 cm | 4 3/4 in. **10585**

15 cm | 6 in. **10586**



Schüssel quadratisch tief | *Bowl deep square* | Coppa fonda quadrata

21 cm | 8 1/4 in. **13071**

# LOFT

Form | Shape | Forma  
10410 | Loft II



Platte flach rechteckig | *Platter rectangular* | Piatto piano rettangolare  
13 x 18 cm | 7 in. **12918**  
18 x 28 cm | 11 in. **12928**



Platte/Teller flach quadratisch | *Dish flat square* | Piatto piano quadrato  
22 cm | 8 2/3 in. **12922**




Schale quadratisch | *Dish square* | Coppa quadrata  
15 cm | 6 in. **12965**



Form | Shape | Forma  
11400 | Trend



Schale | *Dish* | Coppa rotonda  
11 cm | 4 1/3 in. **25811**  
12 cm | 4 3/4 in. **25812**  
13 cm | 5 1/8 in. **25813**



Schale | *Dish* | Coppa rotonda  
21 cm | 8 1/4 in. **25821**



Dipschale | *Dip bowl* | Coppetta salsa  
8 cm | 3 1/8 in. **15396**



Chopstickhalter | *Chopstick holder* | Portabacchette  
**15535**



Porzellanlöffel | *Porcelain spoon* | Cucchiaino porcellana  
**25865**

Form | Shape | Forma  
11940 | Sunny Day / No:Limit  
Ohne Relief | *without relief* | senza rilievo



Teller flach quadratisch | *Plate flat square* | Piatto piano quadrato  
23 cm | 9 in. **16183**  
28 cm | 11 in. **16188**

Form | Shape | Forma  
10410 | Loft II  
Ohne Relief | *without relief* | senza rilievo



Platte flach rechteckig | *Platter rectangular* | Piatto piano rettangolare  
29 x 19 cm | 11 1/2 in. **32679**



Teller tief quadratisch | *Plate deep square* | Piatto fondo quadrato  
23 cm | 9 in. **16513**




Schälchen tief quadratisch | *Bowl deep square* | Piattino fondo quadrato  
13 cm | 5 1/8 in. **35480**



Platte flach rechteckig | *Platter flat rectangular* |  
Piatto piano rettangolare  
18 x 11 cm | 7 in. **12718**



Schüssel quadratisch | *Bowl square* | Coppa quadrata  
23 cm | 9 in. **33281**



Schälchen flach quadratisch | *Dish flat square* | Piattino piano quadrato  
9 cm | 3 1/2 in. **15251**  
12 cm | 4 3/4 in. **15253**

Schälchen tief quadratisch | *Bowl deep square* | Piattino fondo quadrato  
9 cm | 3 1/2 in. **15252**  
12 cm | 4 3/4 in. **15254**

# TREND / NEW TREND

Form | Shape | Forma  
10400 | Trend / New Trend



Teekannen-Unterteil | *Base teapot* | Teiera senza coperchio  
0,40 ltr. | 14 oz. **34211**  
Deckel | *Lid* | Coperchio **34212**



Kaffeekannen-Unterteil | *Base coffee pot* | Caffettiera senza coperchio  
0,30 ltr. | 10 1/2 oz. **34001**  
Deckel | *Lid* | Coperchio **34002**



Zuckerdosens-Unterteil | *Base sugar bowl* | Zuccheriera senza coperchio  
0,15 ltr. | 5 1/4 oz. **34316**  
Deckel | *Lid* | Coperchio **34317**  
Deckel mit Einschnitt | *Lid with indent* | Coperchio con tacca **35185**



Gießer | *Creamer* | Lattiera  
0,03 ltr. | 1 oz. **34403**  
0,15 ltr. | 5 1/4 oz. **34415**  
0,30 ltr. | 10 1/2 oz. **34430**



Schälchen | *Tray* | Coppetta  
9 cm | 3 1/2 in. **35409**



Kaffeebeker | *Coffee mug* | Mug  
0,26 ltr. | 9 1/8 oz. **34654**

Dekor | *Decor* | Decoro  
 800001 | weiß | *white* | bianco



Eierbecher mit Ablage | *Flanged egg cup* | Portauovo  
 35525



Salzstreuer | *Salt* | Spargisale  
 35030

Pfefferstreuer | *Pepper* | Spargipepe  
 35035



Kompott | *Fruit* | Coppetta  
 12 cm | 4 3/4 in.      30512



Schüssel | *Salad bowl* | Insalatiera  
 12 cm | 4 3/4 in.      33012  
 15 cm | 6 in.      33015  
 18 cm | 7 in.      33018  
 21 cm | 8 1/4 in.      33021  
 24 cm | 9 1/2 in.      33024



Buttersauciere | *Buttersauceboat* | Salsiera burro  
 0,10 ltr. | 3 1/2 oz.      35072

Sauciere | *Sauceboat* | Salsiera  
 0,30 ltr. | 10 1/2 oz.      31610



Ascher | *Ashtray* | Posacenere  
 10 cm | 4 in.      37010

# TREND

Form | *Shape* | Forma  
10400 | Trend

Dekor | *Decor* | Decoro  
800001 | weiß | *white* | bianco



Obertasse | *Cup* | Tazza  
0,10 ltr. | 3 1/2 oz. **34612**

Untertasse | *Saucer* | Piattino  
12 cm | 4 3/4 in. **34611**



Obertasse | *Cup* | Tazza  
0,22 ltr. | 7 3/4 oz. **34642**

Untertasse | *Saucer* | Piattino  
15 cm | 6 in. **34636**



Obertasse | *Cup* | Tazza  
0,16 ltr. | 5 5/8 oz. **34622**

Untertasse | *Saucer* | Piattino  
15 cm | 6 in. **34636**



Kaffeebecher | *Coffee mug* | Mug  
0,25 ltr. | 8 3/4 oz. **34650**

Untertasse | *Saucer* | Piattino  
15 cm | 6 in. **34636**



Obertasse nieder | *Cup low* | Tazza bassa  
0,18 ltr. | 6 1/3 oz. **34627**

Untertasse | *Saucer* | Piattino  
15 cm | 6 in. **34636**



Obertasse hoch | *Cup tall* | Tazza alta  
0,18 ltr. | 6 1/2 oz. **34727**

Untertasse | *Saucer* | Piattino  
15 cm | 6 in. **34636**



Untertasse | *Saucer* | Piattino  
12 cm | 4 3/4 in. **34611**  
15 cm | 6 in. **34636**

# NEW TREND

**Form | Shape | Forma**  
 10400 | New Trend

**Dekor | Decor | Decoro**  
 800001 | weiß | white | bianco



Obertasse | *Cup* | Tazza  
 0,10 ltr. | 3 1/2 oz. **34612**  
 Untertasse | *Saucer* | Piattino  
 12 cm | 4 3/4 in. **34611**



Obertasse | *Cup* | Tazza  
 0,22 ltr. | 7 3/4 oz. **34642**  
 Untertasse | *Saucer* | Piattino  
 15 cm | 6 in. **34636**



Obertasse | *Cup* | Tazza  
 0,16 ltr. | 5 5/8 oz. **34622**  
 Untertasse | *Saucer* | Piattino  
 15 cm | 6 in. **34636**



Kaffeebecher | *Coffee mug* | Mug  
 0,25 ltr. | 8 3/4 oz. **34650**  
 Untertasse | *Saucer* | Piattino  
 15 cm | 6 in. **34636**



Obertasse nieder | *Cup low* | Tazza bassa  
 0,18 ltr. | 6 1/3 oz. **34627**  
 Untertasse | *Saucer* | Piattino  
 15 cm | 6 in. **34636**



Obertasse hoch | *Cup tall* | Tazza alta  
 0,18 ltr. | 6 1/2 oz. **34727**  
 Untertasse | *Saucer* | Piattino  
 15 cm | 6 in. **34636**



Untertasse | *Saucer* | Piattino  
 12 cm | 4 3/4 in. **34619**  
 15 cm | 6 in. **34638**

Combi Untertasse | *Saucer combi* | Piattino combi  
 16 cm | 6 1/4 in. **34646**

# TREND

Form | *Shape* | Forma  
 10400 | Trend

Dekor | *Decor* | Decoro  
 800001 | weiß | *white* | bianco



Teller flach | *Plate flat* | Piatto piano  
 16 cm | 6 1/4 in.      **30016**  
 19 cm | 7 1/2 in.      **30019**  
 22 cm | 8 2/3 in.      **30022**  
 25 cm | 9 7/8 in.      **30025**  
 27 cm | 10 5/8 in.     **30027**



Teller tief | *Plate deep* | Piatto fondo  
 19 cm | 7 1/2 in.      **30119**  
 22 cm | 8 2/3 in.      **30122**



Suppentasse | *Soup cup* | Tazza brodo  
 0,25 ltr. | 8 3/4 oz.      **30476**



Suppenbowl | *Soup bowl* | Coppa brodo  
 0,25 ltr. | 8 3/4 oz.      **30725**

Untertasse | *Saucer* | Piattino  
 17 cm | 6 2/3 in.      **30474**



Untertasse | *Saucer* | Piattino  
 17 cm | 6 2/3 in.      **30474**

# NEW TREND

**Form | Shape | Forma**  
 10400 | New Trend

**Dekor | Decor | Decoro**  
 800001 | weiß | white | bianco



**Teller flach | Plate flat | Piatto piano**  
 16 cm | 6 1/4 in.      **31116**  
 20 cm | 7 7/8 in.      **31120**  
 23 cm | 9 in.          **31123**  
 26 cm | 10 1/4 in.      **31126**  
 28 cm | 11 in.         **31128**  
 31 cm | 12 1/4 in.      **31131**



**Teller tief | Plate deep | Piatto fondo**  
 20 cm | 7 7/8 in.      **31220**  
 23 cm | 9 in.          **31223**  
 30 cm | 11 3/4 in.      **31230**



**Platte oval | Platter oval | Piatto ovale**  
 28 cm | 11 in.         **32728**  
 33 cm | 13 in.         **32732**  
 38 cm | 15 in.         **32738**



**Suppentasse | Soup cup | Tazza brodo**  
 0,25 ltr. | 8 3/4 oz.      **30476**

**Suppenbowl | Soup bowl | Coppa brodo**  
 0,25 ltr. | 8 3/4 oz.      **30725**

**Combi Untertasse | Saucer Combi | Piattino combi**  
 16 cm | 6 1/3 in.         **34646**



**Combi Untertasse | Saucer Combi | Piattino combi**  
 16 cm | 6 1/3 in.         **34646**