



Undecorated



AV-1
VENTANA CUP



AV-R14R
PLATTER RECTANGULAR



AV-17
VENTANA MUG



AV-2
VENTANA SAUCER



AV-SQB20
SQUARE BOWL



AV-SQ16
SQUARE PLATE



AV-D3
3 COMPARTMENT SAUCE
DISH



AV-D2
2 COMPARTMENT SAUCE
DISH



AV-D1
SINGLE COMPARTMENT
SAUCE DISH



AV-4S
BOUILLON STACKING



AV-CM
SAUCE BOAT



AV-TB20
TRIANGLE BOWL



AV-SB16
SQUARE BOWL



AV-R20R
RECTANGLE SERVING TRAY



AV-CR22
CRESCENT PLATE



AV-80
DEEP BOWL



AV-S88
SQUARE PLATE



AV-SD21
SCROLL DISH



AV-3
BISQUE BOWL



AV-SQ5
SQUARE PLATE



AV-S16
SQUARE PLATE



AV-V21
VIOLA PLATE



AV-SD
STAR DISH



AV-LC
LOTUS CUP



AV-LT3
LOTUS TRAY FOR AV-
LC



AV-PP4
PEARS PLATE



AV-TR
TRIPOD DISH



AV-TA
TRIAD DISH



AV-FP
FORMA PLATE



AV-SB6
SQUARE BOWL



AV-SB22
SQUARE BOWL



TEMPO BOWL
AV-T76
AV-T77
AV-T78
AV-T79
AV-T26



Oval Bowl
AV-B6
AV-B22
AV-B16
AV-B21



Pan Asia Pedestal
AV-R7
AV-R8
AV-R8F
AV-R16
AV-R21



Service Plate
AV-22
AV-27



AV-QS
Square Dish



ECLIPSE BOWL
AV-E11
AV-E5
AV-E6
AV-E7



OVAL BOWL WITH FOOT
AV-B6F



Oval Coupe Platter
EB-14
EB-28



Satay Platter
AV-L13
AV-L28



AV-Q9S
Square Plate



Moon Plate
AV-MP
AV-MP21



Coupe Rectangle Platter
AV-13
AV-14



SQUARE INSERT PLATE
AV-S4
AV-S5
AV-S8
AV-S20



AV-Q20S
Square Plate



Salt and Pepper Shaker
AV-SS
AV-PS
AV-SPB



Round Coupe Plate
AV-C6
AV-C8
AV-C16
AV-C21
AV-C25



Trio Plate
AV-T8
AV-T20



AV-Q22R
Rectangle Plate



Malibu Bowl
AV-M8
AV-M16
AV-M28



Coupe Square Plate
AV-5
AV-7
AV-9
AV-20



Quartet Plate
AV-Q8
AV-Q20

